



Star Inflatables Instructions

SL100 / SL200 STARLITE KAYAK ASSEMBLY INSTRUCTIONS

1. Unroll the Kayak on a flat surface with top side up.
2. Inflate the side tubes (following the inflation instructions).
3. Next, inflate the I-beam floor until it is firm but not real hard. There is no air release valve, so you need to be careful not to over-inflate this floor. It is also more comfortable to sit on if the floor is not too hard. When the floor is fully inflated you should be able to push your thumb into it about ½" without too much effort. Be careful, when off the water, to deflate the floor or keep it out of the sun.
4. Thwart Assembly:
 - a. Inflate the thwart (or backrest) about one half of full inflation.
 - b. Insert the thwart into the kayak at the most comfortable paddling position for you. Remember that this thwart can be adjusted to any position inside the boat.
 - c. When you place the thwart in your chosen position with the valve facing toward the back of the kayak, and the thwart seam should be facing downward.
 - d. Two webbing straps hold the thwart in place. Feed one webbing strap down through the drain hole in the attached floor and back up through the adjacent hole. Place the two loops of the webbing strap onto the cambuckle and clip it to the d-ring on one end of the thwart. Repeat for the other side of the thwart.
 - e. If you have the SL200 model, insert the second thwart now following the same procedure.
5. Now finish inflating the thwart to the pressure that is most comfortable to you. Sometimes slightly soft is more desirable.

Star Inflatables
232 Banks Road
Travelers Rest SC 29690
Toll Free: 877-900-2628
Or 864-836-2800